

PORTA ON/OFF
PORTA TIME
CC - (OFF USB MIDI ALL)
OCT -4
OCT -3
OCT -2
OCT -1
OCT +/-0
OCT +1
OCT +2
OCT +3
OCT +4
OCT +5
SEQ: TEMPO
GATE TIME
SELECT - WRITE PATTERN 1 - 16
TUNE
CH
CLOCK
TRANSP
VEL: MODE/DEPTH
AUTOOFF - DEMOLED
CHAIN
MOD HOLD
PB RANGE
DELAY LEV
TIME
FEEDBACK
2- WHILE POWER ON -> USB DRIVE
SEQ: STEPS: NUMBER
SHUFFLE
SCALE
ORDER
REST/SKIP



PORTA ON/OFF — PORTA TIME — CC - (OFF USB MIDI ALL) — OCT -4 OCT -3 OCT -2 OCT -1 OCT +/-0 — OCT +1 OCT +2 OCT +3 OCT +4 OCT +5

SEQ: TEMPO — GATE TIME — SELECT - WRITE PATTERN 1 - 16

TUNE — CH — CLOCK — TRANSP — VEL: MODE/DEPTH — AUTOOFF - DEMOLED — CHAIN — MOD HOLD — PB RANGE — DELAY LEV — TIME — FEEDBACK

2- WHILE POWER ON -> USB DRIVE

SEQ: STEPS: NUMBER — SHUFFLE — SCALE — ORDER — REST/SKIP